



FLEXIGLASS FITTING MANUAL - SECTION 5.1E

PLT610 Cover plate fit - ISSA0

Note: Familiarise yourself with the instructions before you start to ensure you are clear on all aspects of the fit

SAFETY EQUIPMENT

- Hearing protection as required
- Eye protection as required

TOOLS REQUIRED

- #40 Torx bit.
- 10mm hex socket.
- Ratchet or pneumatic driver for above.
-
-

MATERIALS & PARTS REQUIRED

Part No.	Description	Qty.
PLT610	Cover plates right and left hand.	1 pair

The **PLT610** is suitable for use on both Holden RG Colorado and Isuzu D-Max 2012. It is designed to cover the unpainted area shown in **ILL 1** that is created when a cab-rack (protector) is removed from the tub of some models of these vehicles.



- 1 Remove the cab-rack using a **#40 Torx driver** and **10mm socket** to release six cup head screws inside the tub and five 10mm hex head screws along the front. Retain the six cuphead screws.
- 2 Remove the plastic protective film from the pair of plates and locate them over the body holes as shown in **ILL 2**.

NOTE: The holes in the plates in the first batch are slightly misaligned, this will be corrected in future. In the meantime they will fit but all three screws must be started in their threads **before** tightening.

- 3 Fit the cup head screws back into their threads and tighten them in rotation so that the plate pulls down evenly.

NOTE: As **PLT610** will not be necessary for all canopy fits to Colorado & 2012 D-Max **the unused part must be journaled back into stock to maintain accurate stock levels for re-order timing.**

